



Liberty Bags



5308 Irwindale Ave., Irwindale, CA 91706

How to Print 600D Polyester

INK

- PA series from Nazdar
- Plastisol* ink

DRYER SETTING

- PA series - Air dry for 8 hours.
- Plastisol ink - 250 degrees heat dry 15 seconds + air dry for 15 minutes

OTHER RECOMMENCATIONS

- Keep heat under 375 degrees and keep the heating time less than 30 seconds per press. If more heat is needed, the operator can simply press multiple times

*Plastisol is a suspension of PVC particles in a plasticizer; it flows as a liquid and can be poured into a heated mold. When heated to around 177 degrees Celsius, the plastic and plasticizer mutually dissolve each other. On cooling the mold below 60 degrees C, a flexible, permanently plasticized product results.

Liberty Bags is providing the above information as a reference guide only. Actual temperatures, drying times, inks, or other elements of the printing process might vary based on equipment, location or any other number of factors. Liberty Bags is happy to provide a sample swatch book of our material to run tests on prior to printing and assumes no liability for providing the above information. For a swatch book print sample test kit please email susan@thousandoakscorp.com and request a swatch book.